



INSTRUCTION MANUAL FOR SIDE BY SIDE

**READ THE INSTRUCTIONS AND WARNINGS
IN THIS MANUAL CAREFULLY BEFORE USING THIS FIREARM**

Table of Contents:

- 1. Introduction**
- 2. Safety Guidelines**
- 3. Shotgun Overview**
 - A. Parts and Terminology**
 - B. Basic Operation**
- 4. Loading and Unloading**
- 5. Firing the Shotgun**
- 6. Safety Mechanism**
- 7. Maintenance and Cleaning**
- 8. Storage**
- 9. Troubleshooting**
- 10. Disclaimers and Warnings**



Model-1



Model-2

1. Introduction:

Thank you for choosing the Side-by-Side Double-Barrel Shotgun with a Two-Hammer System. This user manual aims to provide you with essential information to operate the shotgun safely and effectively. Before using the firearm, it is crucial to read and understand this manual thoroughly.

2. Safety Guidelines:

Always treat the shotgun as if it is loaded. Never point the firearm at anything you do not intend to shoot.

Keep your finger off the trigger until you are ready to fire.

Be sure of your target and what lies beyond it. Always ensure a safe shooting

Wear proper eye and ear protection when shooting.

Store the shotgun and ammunition securely, out of reach of unauthorized users and children.

Never rely on the safety mechanism alone; it's an additional precaution, not a guarantee.

Keep the muzzle pointed in a safe direction at all times.

Avoid alcohol, drugs, or any substances that may impair your judgment while handling the shotgun.

3. Shotgun Overview:

A. Parts and Terminology:

With the press of a conveniently located button on the right side, you can effortlessly fold the shotgun for easy storage and portability.

Barrel Selector: A switch that allows you to choose which barrel to fire first (if equipped).

Trigger: The mechanism that initiates the firing process when pressed.

Safety: A lever that engages or disengages the safety mechanism.

Hammers: Two hammers, one for each barrel, that strike the firing pins to ignite the cartridges.

Extractor/Ejector: Mechanisms that remove spent shells from the chamber after firing.

Folding Lever:

A folding lever is a feature found on some shotguns designed for compactness and portability. This lever, often located on the side or underneath the shotgun, allows the shooter to fold the barrel(s) and stock, making the shotgun easier to carry and store. The key difference between the two models lies in their folding mechanisms; one features a lever located at the right side (model1) , allowing you to fold the barrel, while the other model (model2) integrates the lever with the trigger guard for seamless folding action.

B.Basic Operation:

The side-by-side double-barrel shotgun operates by manually breaking it open or pumping the forend to load shells into the chambers. The shotgun features two hammers, each corresponding to one barrel. The hammers are cocked when you break open the shotgun or operate the pump action. Once the shotgun is loaded, you can select which barrel to fire first (if applicable) using the barrel selector. Pulling the trigger releases the corresponding hammer, firing the cartridge in the selected barrel.

4. Loading and Unloading:

Make sure the safety is engaged and the muzzle is pointed in a safe direction.

To load the shotgun, break it open or operate the pump action, exposing the chambers.

Insert the appropriate shotgun shells into each chamber, ensuring they are fully seated.

Close the shotgun securely until you hear a distinct click or feel it lock into place.

To unload the shotgun, open the action and remove the unfired shells. Double-check that the chambers are empty.

5. Firing the Shotgun:

Ensure you are following all safety guidelines mentioned earlier.

Select the desired barrel (if applicable) using the barrel selector.

Aim the shotgun at your target, keeping your finger off the trigger.

When ready to fire, disengage the safety (if engaged) and gently squeeze the trigger.

Repeat the process for the second shot if needed.

6. Safety Mechanism:

The shotgun is equipped with a safety lever, typically located behind the hammer. When engaged, the safety prevents the trigger from being pulled, adding an extra layer of security. To fire the shotgun, disengage the safety by pushing or sliding the lever into the "fire" position.

7. Maintenance and Cleaning:

Ensure the shotgun is unloaded and the safety engaged.
Disassemble the shotgun as per the manufacturer's instructions.
Clean the barrel, action, and other components using appropriate cleaning tools and solvents.
Inspect the shotgun for any signs of wear or damage. If you notice anything unusual, consult a professional gunsmith.
Apply a light coat of gun oil to protect the metal parts from rusting.
Store the shotgun in a clean, dry place.

8. Storage:

When storing the shotgun for an extended period, follow these

Unload the shotgun and visually inspect the chambers to ensure it is empty.

Store the shotgun and ammunition separately in locked cabinets or safes.

Keep the firearm in a cool, dry place to prevent rust or corrosion.

9. Troubleshooting:

If you encounter any issues or malfunctions with your shotgun, stop using it immediately and contact a qualified gunsmith for inspection and repair. Do not attempt to modify or repair the shotgun yourself unless you are a trained professional.



10. Disclaimers and Warnings:

Follow all local, state, and federal laws regarding the possession, use, and transport of firearms.

Misuse or mishandling of the shotgun can result in serious injury or death. Always exercise caution and proper safety measures.

The manufacturer is not responsible for any damages or injuries resulting from the use or misuse of the shotgun.

Remember, always prioritize safety and responsible firearm ownership. Happy shooting!



www.baliklisilah.com

